

ARRANCADORES

SONTUNE®

Código	Referencia	Voltaje (V)	Corriente (A)	Frecuencia	Material
54505	LE1-D09	110	5,5-8	60Hz	Base y cubierta plástica
50275	LE1-09		7-10		
54515	LE1-D12		9-13		
54530	LE1-D18		12-18		
54520	LE1-25		17-25		
54535	LE1-D32		23-32		

Código	Referencia	Voltaje (V)	Corriente (A)	Frecuencia	Material
50280	LE1-D09	220	4-6	50/60Hz	Base y cubierta plástica
50285			5,5-8		
50205			7-10		
50260	LE1-D012		9-13		
50215	LE1-D018		12-18		
50220	LE1-D025		17-25		
50225	LE1-D032		23-32		

Código	Referencia	Voltaje (V)	Corriente (A)	Frecuencia	Material
54540	SE1-N09M7	110	7-10	50/60Hz	Base Metálica y cubierta plástica
54510	SE1-N12M7		9 -13		
54545	SE1-N18M7		12 -18		
50255	SE1-N25M7		17-25		
54525	SE1-N32M7		23-32		

Código	Referencia	Voltaje (V)	Corriente (A)	Frecuencia	Material
50230	SE1-09	220	7-10	50/60Hz	Base Metálica y cubierta plástica
50235	SE1-12		9 -13		
50240	SE1-18		12 -18		
50245	SE1-25		17-25		
50250	SE1-32		23-32		
50265	LE1-D040		30-40		
50270	LE1-D050		37-50		

Intertek
CERTIFICADO
RETIE

54505-54535



50280-50225



54540-545225



50230-50270